

SRN NOMAD 360 by Fox Fury

This ultimate scene light provides up to 7,000 lumens for up to 24 hours. The adaptive Nomad 360 converts from an area light to spotlight to 360° scene light in seconds by sliding the diffuser lens and opening/closing the light head. Its portable, waterproof and self-contained design allows it to travel to (and be used in) places that standard scene lights, street lamps and vehicle mounted lights cannot reach.

In around 20 seconds, you'll be able to deploy the tripod legs and raise the telescoping head up over 8 ft. tall to illuminate the work area. It is rechargeable and the cordless design eliminates the need for a noisy, heavy generator. If you have external power, the 360 provides continuous light. The 360 is used at command posts, accident scenes, temporary shelters, checkpoints and job sites around the globe.



Light Intensity and Battery Life

Intensity	Lumens	Battery Life
High	7,000	3 hours
Medium	2,100	5 hours
Low	700	9 hours

LED/Light Output

- Up to 7,000 torch lumens
- 100 watt power consumption
- See up to 1.0 mi (1.65 km)

Features

- 12° spotlight, 120° area light, or 360° scene light
- Deploys in 20 seconds
- 3 intensities (low, medium, high)
- Telescopes up to 99" (251.5 cm)
- Rotating head (340°)
- Self-contained
- Battery life indicator
- Hold-down clamp

Battery

- Rechargeable lithium-ion 200 WH battery system
- Fully recharges in 7 hours; 500+ charge cycles
- Power supply connects to AC or car battery
- Battery is replaceable by user

Portability

- Folds into a 38.5" (97.8 cm) long, 4.6" (11.7 cm) diameter poster-tube for easy carry and storage
- Shoulder strap
- Weight - 23.0 lbs /10.5 kg
- Max Height - 99.0" / 251.5 cm

Durability

- Nylon 66 body with 6061-T6 aluminum head
- Fire scene ready
- IPX7 - waterproof to 3 ft | 1 m

Warranty

- Two (2) year warranty on all manufacturer defects